

# Short Instructions Loading and Driving Tiger 6S

Edition 1

02/2024



***ROPA***

Imprint

All rights reserved

©Copyright by

ROPA Fahrzeug- und Maschinenbau GmbH

Sittelsdorf 24

D-84097 Herrngiersdorf

Phone: + 49 – 87 85 – 96 01 0

Fax: + 49 – 87 85 – 56 6

Internet [www.ropa-maschinenbau.de](http://www.ropa-maschinenbau.de)

email: Jan.Steinlehner@ropa-maschinenbau.de

This document may only be reprinted or otherwise reproduced – even in excerpts – with the express approval of ROPA GmbH. Any type of reproduction, distribution or storage on data medium in any form and of any type not authorised by ROPA GmbH forms a violation of current domestic and international copyright law and will be judicially prosecuted.

Publisher responsible for the content:

ROPA Fahrzeug- und Maschinenbau GmbH

# Contents






<b>1</b>	<b>Loading.....</b>	<b>7</b>
1.1	Transport draft for low-loader transport of machine without additional chassis (6-row RR).....	9
1.2	Transport draft for low-loader transport of machine with additional chassis (6-row RR).....	10
1.3	Lashing eyes for transport by low-loader/ship.....	11
<b>2</b>	<b>Driving.....</b>	<b>13</b>
2.1	Steps to drive a Tiger.....	15
2.2	Battery emergency shutdown.....	16
2.3	Ladder driver's cabin.....	17
2.4	Steering column.....	18
2.5	Battery main switch function.....	19
2.6	Switches on roof console.....	20
2.7	Operating components on the floor of the driver's cabin.....	22
2.8	Start/shut down diesel engine.....	23
2.9	Operating mode change.....	25
2.10	Driving.....	25
2.11	Selection of the driving direction (forward+/backward).....	28
2.12	Main steering switch.....	29
2.13	Joystick with multi-functional handle.....	30
2.14	Steering in operating mode "Road".....	31
2.14.1	U-turn steer.....	31
2.14.2	Steering w/o offset.....	32
2.14.3	Crab steering.....	32
<b>3</b>	<b>Index.....</b>	<b>33</b>



# 1 Loading




# 1.1 Transport draft for low-loader transport of machine without additional chassis (6-row RR)



All data in mm.



1.2
Transport draft for low-loader transport of machine with additional chassis (6-row RR)




All data in mm.

### 1.3 Lashing eyes for transport by low-loader/ship


The front axle is equipped with eyelets for clamping it down in ground direction. These eyelets are located on the right and left next to the mount point for the axle support cylinders. There are also eyelets on the right and left side of the main frame, one on each side, in the area of the 1st and 2nd rear axles. Each eyelet may be loaded with a maximum tensile force of 5000 daN. Clamping chains etc. must not be stretched over mechanical parts.




*Regular low loader for road transport with minimum transport height*




*Lashing eye on the front axle*



*Lashing eyes on the front axle*



*Lashing eye behind the 1st rear axle*



*Lashing eye over the 2nd rear axle*



*Image shows as an example euro-Tiger (MAN)*

The machine has no attachment points by which it can be lifted. For hoisting it into a ship for example, special, approved and TÜV-approved lifting devices are necessary.

## 2 Driving






## 2.1 Steps to drive a Tiger

- Switch on the Power supply at the emergency switch. ([See Page 16](#))
- Lift the climbing ladder driver's cabin downwards. ([See Page 17](#))
- Adjust the steering column ([See Page 18](#))
- Turn on battery main switch. ([See Page 19](#))
- Turn on the rotating beacons. Fold out and adjust the mirror. Turn on driving light. ([See Page 20](#))
- Inform you about the operating components on the floor of the driver's cabin. ([See Page 22](#))
- Start diesel engine. ([See Page 23](#))
- Make sure that operating mode "Field" is switched on. ([See Page 25](#))
- Release the parking brake. ([See Page 25](#))
- Select the driving direction. ([See Page 28](#))
- Raise the lifting unit with the additional chassis until stop. ([See Page 28](#))
- Unlock the main steering switch. ([See Page 29](#))
- Steering rear wheels with joystick ([See Page 30](#)) or select a steering mode. ([See Page 31](#)) ([See Page 32](#)) ([See Page 32](#))

Drive slowly and carefully!

- Engage the parking brake. ([See Page 25](#))
- Shut down the diesel engine. ([See Page 23](#))
- Switch off the ignition. ([See Page 23](#))
- Switch off the main battery switch. ([See Page 19](#))
- Close the driver's cabin.

## 2.2 Battery emergency shutdown



Power supply at the emergency switch turned on ("*Battery emergency shutdown*")

### ATTENTION




#### **Danger of machine damage.**


If this switch is tilted backward while the ignition is on, it can lead to data loss.

It may also seriously damage the exhaust gas after-treatment system (SCR system) (only RT6Sd).

## 2.3 Ladder driver's cabin



*Ladder to driver's cabin in transport respectively working position*



- (1) Release lever driver's cabin ladder
- (2) Rod driver's cabin ladder
- (3) Rope driver's cabin ladder


- Unlock ladder by pulling the release lever (1), fold it down by pulling the rod (2).
- To unlock when descending, press the lever on the lock (4) with your foot.

### ADVICE



We recommend to fold up and lock this ladder during lifting! Thus, the forbidden climbing on the machine is not possible while driving!

## 2.4 Steering column



### **DANGER**



**Hazard of deadly injuries if the steering column is moved while driving.**

In this case, the machine can go out of control and cause the severest damages.

- Therefore, NEVER move the steering column while driving!

#### **Rotating handle (1) height adjustment**

Release rotating handle (1) (turn to the left), move the steering column to the desired height, retighten the rotating handle (turn to the right) and block the steering column. Check if the steering column is securely fixed in the desired position.

#### **Lever (2) incline adjustment top**

Push lever (2) upward and pull or push steering column into the desired position. Release lever (2). Check if the steering column is securely fixed in the desired position.

#### **Lever (3) incline adjustment bottom**

Push lever (3) using the foot, move the steering column into the desired position. Release lever (3). Check if the steering column is securely fixed in the desired position.

## 2.5 Battery main switch function


When you disconnect the power supply from the main battery switch (77) the power supply does not switch off until 6 minutes later (provided the ignition lock is in 0-position). If you forget to switch off the main battery switch (77) the battery disconnect relay will switch off automatically 120 hours after switching off the ignition. In this case you have to switch the main battery switch (77) OFF/ON once before the next time you turn on the ignition.



swung upward = OFF

swung downward = ON

### ADVICE




The function of the battery main switch can be overridden by the following systems:

- Control device diesel engine exhaust after-treatment
- Telematics
- Park heating
- Ladder light
- Engine compartment lighting



## 2.6 Switches on roof console




- (58) Radio with Bluetooth and USB (see separate operating manual)
- (59) Rotating switch to fold in/out the left rearview mirror
- (60) Switch for rotating beacons
- (61) Not used
- (62) Not used
- (63) Not used
- (64) High beam control (above) / turn signal control (below)
- (65) Switch parking/driving lights
- (66) Switch flashing warning system
- (67) Switch mirror heating

### ADVICE



The mirror heating switches off to conserve battery life in few minutes with the stopped diesel engine.

- (68) Four-way switch for electrical adjustment of right and left outer mirrors.
- (69) Rotating switch to fold in/out the right rearview mirror
- (70) USB double socket 5V / 3.6A (USB-A and USB-C)
- (71) Dummy cap, installation option for radio equipment, cable for voltage supply located behind the dummy cap in the roof console
- (72) Hands-free communication microphone

**ATTENTION**

The voltage transformer can become damaged if these USB ports are overloaded.

- (73) USB double socket 5V / 3.6A (USB-A and USB-C)
- (74) Internal lamps on driver's cabin ceiling LED
- (75) Switch for LED internal lamps on driver's cabin ceiling
- (76) Not used
- (77) Battery main switch ([See Page 19](#))
- (78) Roof console storage compartment


**WARNING**

**Hazard of objects falling down from the storage compartment in the roof console.**

During jerky movements of the machine or driving around curves, these objects may fall out and severely injure the driver.

- Do not put any heavy or sharp objects in this storage compartment. Whenever possible, place such items in the storage compartment on the cabin rear panel.

## 2.7 Operating components on the floor of the driver's cabin



- (1) Opener for cleaning flap
- (2) Foot switch autopilot
- (3) Foot switch driving direction
- (4) Brake pedal
- (5) Drive pedal

## 2.8 Start/shut down diesel engine

If the drive pedal is not in resting position during starting, then for safety reasons, traction drive is blocked. The block remains for so long until the drive pedal is completely released and pressed again.

### ATTENTION





#### Danger of machine damage.

Use of chemical starting aids (e.g. Startpilot etc.) is expressly prohibited, because this may lead to injuries and to damage to the machine.

The ignition lock has three switching positions:

- Position 0: Shut down diesel engine/ignition off – the key may be removed
- Position I: Ignition on, the diesel engine is ready for start
- Position II: Start diesel engine (not connected)



The diesel engine is started with the START key  and shut down with the STOP key .

If the diesel engine does not start immediately, then the electronic system switches off the starter after a certain period of time. In this case, wait at least 2 minutes until the next try to start so that the starter can sufficiently cool down.

Help for engine starting *"Jump starting and charging the battery"*

### CAUTION




It is necessary for the safe operation of the control units that the ignition is switched off at least once every 24 hours (position 0). Wait until the green LED on the colour terminal goes off before switching the machine on again. Only then the machine is considered to be switched off completely.

### ADVICE







To start the diesel engine press and hold the START key (27) for at least 3 sec.. If the START key is pressed too briefly, a note appears on the terminal.



If the diesel engine cannot be started due to a starting block, the R-Touch displays the following warning icon: 

This warning icon and one of the following alternately flash on the R-Touch:

	Please close engine housing door left		Please close engine housing door right
	Please close rear cover		Please close bunker door


Let the diesel engine idle for a short time before shutting it down. If the diesel engine is shut down at high speed, then the turbo charger runs on after the oil pressure has already fallen.

This leads to lack of lubricant and therefore to unnecessary wear on bearings of the fast-running turbine of the turbocharger.

To shut down the diesel engine

- Press STOP key (**18**).
- Only in case of emergency, shut down the diesel engine by moving the ignition lock to position 0.

#### ADVICE



The diesel engine can be started and shut down from the ground.

There must be no one in the driver's seat and the ignition must be on.

Press and hold the deadman switch (**1**) and press and hold the two keys (**8**), (**9**) until the diesel engine has started and the beeping of the reversing signal has stopped or the working floodlights on the cabin roof stop flashing. If the keys are released before the reversing beeper has stopped or the working floodlights on the cabin roof have stopped flashing, the engine will shut down immediately.


To shut down the diesel engine press and hold the same three keys.





## 2.9 Operating mode change

- The operating mode can be changed either when the machine is stopped or while driving with low speed.
- Select the desired operating mode using keys (32) and (33) on the keypad III.



(32) Operating mode "Road"

(33) Operating mode "Field":

### ADVICE




When changing from "Road" to "Field" mode during driving, the 3rd drive motor and the all-wheel drive are only engaged when the machine comes to a standstill.

If the 3rd drive motor and the all-wheel drive are not fully engaged in the "Field" operating mode, the main lifter drive cannot be switched on.

## 2.10 Driving

You control the driving speed of the machine using the gas pedal. The more you press on the pedal, the faster the machine drives. When you completely release the gas pedal, the machine strongly brakes due to the hydrostatic drive.



(3) Foot switch driving direction

(4) Brake pedal

(5) Drive pedal



**(39)** Parking brake (hand brake)

Hydrostatic drives are deemed very safe. The following measure additionally increases this safety, if there should be any operating faults of the drive. If, when releasing the driving pedal, the machine should neither reduce driving speed nor stand still, then a safety circuit is activated by engaging the parking brake (39).



This safety circuit bypasses the standard control behaviour of the hydraulic system and opens a safety valve that quickly shuts off the traction drive. If, in the extremely improbable case of failure of all safety devices, the machine still does not stop, then shut off the diesel engine with the STOP key (26) or ignition key as quickly as possible. ("*Ignition lock*") (See Page 24)


### **DANGER**



**Danger of severe rear-end collisions with injuries hazardous to life or even deadly when engaging the parking brake or shutting off the diesel engine, while the machine is driving.**


- Therefore, take this EMERGENCY-STOP measure only in extreme emergencies and try to warn following traffic by pressing the foot brake pedal several times and switching on the hazard warning system.














If the vehicle should move only very slowly after switching to the operating mode "Road", then the R-Touch displays the icon: .

Fold the unloading conveyor articulation part completely in.



If the supply pressure in hydrostatic drive is too low (15 bar) the orange warning icon appears:  Please stop and call customer service!

If it is not possible to move the vehicle, then the cause for this is shown on the R-Touch:

	Please release parking brake.	
	Please release brake pedal.	
	Error of the drive pedal sensors!	Call customer service
	Brake-air of pressure brake reservoir too low!	
	Release pressure parking brake too low!	
	Supply pressure in hydrostatic drive is very low (12 bar)!	
	Coupling pressure of multiple disc clutch CVR gearbox too low!	
	Lubrication CVR gearbox failed!	
	Temperature in CVR gearbox is too high!	
	TR5 reduction gears lubrication failed!	
	Temperature in TR5 reduction gears too high!	

## 2.11 Selection of the driving direction (forward+/backward)


Foot switch driving direction (3):

NOT PRESSED

Driving direction "forwards"

PRESSED

Driving direction "backwards"



(3) Foot switch driving direction


(5) Drive pedal

### ADVICE



For driving backwards in the operating mode "Road", the drive pedal must be released completely. Then, wait until the machine comes to a complete standstill (0.0 km/h). Only then the foot switch "Driving direction" may be pushed and held in this position.



If the lifting unit is still lowered (i.e. the scalper is still on the ground), then an automated reversing block is in effect. This avoids damage which otherwise could be caused by driving backwards with the lifting unit lowered. The R-Touch displays the icon .

To override the back run lock *"Additional chassis coupling"*


While driving backwards, a warning signal sounds drawing attention of other people to the reversing movement.



**Mini joystick (1)** forward/backward (lower/raise three-point suspension, only with engine running)

**FORWARD:** To lower the lifter slow proportionally, press the mini joystick (1) forward. The further you press the mini joystick (1) forward, the higher the lowering speed is.

**BACKWARD:** Raise three-point suspension (lifter and topper).

**2.12 Main steering switch****(44)** Main steering switch**DANGER**

When the main steering switch is unlocked the driving speed of the machine is limited.

- When driving on public roads and paths, the main steering switch must generally be locked.
- It may **ONLY** be unlocked for driving through narrow curves and at low speed (below 12 km/h).

swung right = unlocked

Steering of articulation and rear axles is possible.


swung left = locked

Steering of articulation and rear axles is locked.



## 2.13 Joystick with multi-functional handle

For better orientation, a transparent sticker is located on the side window of the driver's cabin containing the following schematic overview of all functions of the joystick with multifunctional handle.



### Joystick movements



- |   |                            |  |
|---|----------------------------|--|
| ← | Press joystick to the left | = Rear axles steer to the left (" <i>Steering rear wheels with joystick</i> ").  |
| → | Push joystick to the right | = Rear axles steer to the right (" <i>Steering rear wheels with joystick</i> "). |

## 2.14 Steering in operating mode "Road"

In the operating mode "Road", the rear wheels may be steered by moving the joystick back and forth, if the main steering switch (44) is unlocked. When driving on public roads and paths, the main steering switch must generally be locked. It may ONLY be unlocked for driving through narrow curves and at low speed (below 12 km/h). When the main steering switch is unlocked the driving speed of the machine is limited.


### DANGER



#### Hazard of deadly injuries when driving with unlocked main steering switch.

In case of some technical faults, uncontrolled swinging movements of the vehicle at higher speeds may occur. This might seriously endanger or cause deadly injuries to other participants in traffic.

- Therefore, the main steering switch may be unlocked on public roads and paths only under the conditions stated above and only for as long as indispensably required.




### 2.14.1 U-turn steer



The conditions already mentioned for activation of offset-steer apply here. As the name implies, the steering variant U-turn serves almost exclusively for turning the machine in the smallest space.

In this variant the vehicle is programmed so that the machine U-turn can be relatively simply performed without further switching even in a limited space. Once the steering variant "U-turn" is activated shortly pressing the key (2) on the joystick, the articulated joint bends always matching the front wheels. Thus, it follows any movement of the front wheels. At the same time, the rear wheels move opposite to the front wheels. Thus, the manoeuvrability of the machine is significantly improved.






### 2.14.2 Steering w/o offset




The conditions already mentioned for activation of offset-steer apply here. When the steering variant "Steering w/o offset" is activated (press key (2) on the joystick for 1 second), then the articulation joint is automatically moved to 0° position and remains in this position. The rear wheels move opposite to the front wheels and so support the steering movement of the front wheels. The steering behaviour of the machine during steering without offset is therefore the same as for U-turn, with the difference, that the articulation does not also steer during steering without offset.



### 2.14.3 Crab steering



The conditions already mentioned for activation of offset-steer apply here. To activate the steering variant "Crab steering" press the multi-key (11), hold it and then press the key (2) on the joystick for 1 sec.. Now the rear wheels move in the same direction as the front wheels. Thus, the vehicle can drive diagonally (e.g. to the pile).



## 3 Index



**B**

Battery disconnect relay.....	19
Battery emergency shutdown.....	16
Brake pedal.....	22

**C**

Cleaning flap.....	22
Crab steering.....	32

**D**

Drive pedal.....	22
Driving.....	25

**F**

Flashing warning system.....	20
------------------------------	----

**H**

High beam control.....	20
------------------------	----

**I**

Interior lights.....	20
----------------------	----

**J**

Joystick with multi-functional handle.....	30
--	----

**L**

Ladder driver's cabin.....	17
Low-loader transport.....	11

**M**

Main steering switch.....	29
Mini joystick.....	28
Mirror heating.....	20

**O**

Operating components on the floor.....	22
Operating console.....	26
Operating mode change.....	25

**R**

Rearview mirror.....	20
Roof console.....	20
Roof console storage compartment.....	20
Rotating beacons.....	20

**S**

Selection of driving direction.....	28
Ship transport.....	11
Shut down diesel engine.....	24
Start diesel engine.....	23
Steering column.....	18
Steering w/o offset.....	32

**T**

Transport draft.....	10
----------------------	----

**U**

U-turn steer.....	31
-------------------	----

